


Super Nova 250S Battery Charger/Discharger Schematic Diagram

Black Lines: →
Use 'SET STOP' Button
Red Line: →
Use 'Down' or 'Up' Buttons



Data Reference During Charging & Discharging

By pressing both the Up & Down buttons simultaneously the following data will be displayed. Then scroll by pressing either Up or Down buttons:

In/Out Voltage - Vi & Vo
 Charge Voltage - Vp & Va
 Discharge Voltage - Vs & Vc
 Char. (In mAh's)
 Disc. (In mAh's)
 Char. (Time)
 Disc (Time)

Vi = Voltage In.
 Vo = Voltage Out
 Vp = Peak Voltage.
 Va = Average Voltage
 Vs = Discharge Start Voltage
 Vc = Discharge Cut - Off Voltage

Note Your Manual Settings

No.	Type	Cells	Cap	Chg	Dis	Note
0						
1						
2						
3						
4						
5						
6						
7						
8						
9						